

The SpeedCheck Manager software allows you to easily set up, program, update, and perform maintenance on your SpeedCheck radar speed sign. This software supports Bluetooth<sup>®</sup> wireless technology or hardwiring for local programming.

- ✓ Set up the display from up to **50 ft away** with Bluetooth wireless connection
- ✓ Streamlined interface and display settings let you program each sign in around **five minutes**
- + **Data Logger (optional):** Collect and download vehicle speed data for use in the Traffic Analysis software
- + **Scheduler (optional):** Set up and manage unlimited operating schedules with a 2-year exception list
- + **Inputs/Outputs (optional):** Configure external devices such as beacons and strobes, or allow external devices to manage display operation

### COMPATIBLE WITH:


SPEEDCHECK-15, SPEEDCHECK-18,  
SPEEDCHECK ADVISORY

### REQUIRES:

Windows 7\* or 10 (32- or 64-bit)  
laptop/desktop computer

\* Laptops running Windows 7 and desktop computers may require a Bluetooth dongle.

## SOFTWARE AT A GLANCE



**HIGH-SPEED CUTOFF**  
Choose what happens to the display when drivers reach excessive speeds: blanks out, flashes the speed limit, or continues to flash their speed.

**OPERATING MODES**  
Configure the display's speed parameters: set the road's speed limit, the speeds that trigger the digits to flash and display the optional "SLOW DOWN" message, and the minimum and maximum display speeds.

**SIGN OPERATION**  
Run the SpeedCheck continuously, from an external device, or through our optional Scheduler add-on.

**Display:** On  
**Data Collection:** On  
**Speed Limit:** 20  
**Violation Alert Speed:** 25  
**SLOW DOWN Speed:** 30  
**High Speed Cutoff:** 50  
**Minimum Display Speed:** 10

[Click here to download the manual.](#)